

C clamp installation schematic: branch and parallel connection

Not to scale

a) Branch connection (T connection)



b) Parallel connection (continuing two conductors)



Installation notes

1. The main conductor sits in the larger part of the C and the branch conductor in the smaller part.
2. The end of the branch conductor protrudes slightly from the edge of the C clamp.
3. The branch conductor is bent outside the C clamp, after crimping.
4. The C clamp is closed with a dedicated crimping tool and a matching die.
5. The connection is permanent and is used at accessible points of the earthing network.

Key

- 1 Crimped copper C clamp
- 2 Main stranded copper conductor
- 3 Branch stranded copper conductor

This document is not contractual; we may update product design, dimensions, weights and images without prior notice.

گروه کالوت
KALOT GROUP
Protect Today For Tomorrow
Since: 1972 تاسیس: ۱۳۵۱
www.kalot.ir · Tel +98 21 2268 8852