
Where to install the stainless steel bonding point

Views not to scale


Ø80 × 2.5 · L 232.5 · M10 × 1.25

KALOT GROUP · TECHNICAL ILLUSTRATION · NOT TO SCALE


4. Electrical room wall, next to the earth bar




3. Beams and tie beams



2. Basement and foundation wall



1. Concrete column



In all these locations the bonding point plate sits flush with the concrete surface and is connected to the reinforcement from behind; the earthing or bonding conductor is fixed to its bolt with a cable lug and runs to the earth bar, down conductor or equipment.

گروه کالوت
KALOT GROUP
Protect Today For Tomorrow
Since: 1972 تاسیس: ۱۳۵۱
www.kalot.ir · Tel +98 21 2268 8852

This document is not contractual; we may update product design, dimensions, weights and images without prior notice.