
# U clamp connection modes

Views not to scale


**UBDV**

KALOT GROUP · TECHNICAL ILLUSTRATION · NOT TO SCALE


### 4. Conductor perpendicular to the reinforcing bar





### 3. Conductor in line with the reinforcing bar




### 2. Conductor perpendicular to the earth rod




### 1. Conductor in line with the earth rod




The U clamp has two conductor holes: the centre hole for a conductor in line with the earth rod or reinforcing bar, and the cross hole, clear of the U-bolt legs, for a conductor perpendicular to it. The clamp fits copper, copper-bonded or stainless steel earth rods and ribbed reinforcing bars. Views are seen from the nut side.

This document is not contractual; we may update product design, dimensions, weights and images without prior notice.

گروه کالوت
KALOT GROUP
Protect Today For Tomorrow
Since: 1972 تاسیس: ۱۳۵۱
www.kalot.ir · Tel +98 21 2268 8852